

MABARA CONTROLLERS WIRES TO YASKAWA DRIVE CONNECTION

MABARA CONTROLLER WIRE DETAILS						
DRIVE INPUT	FROM TERMINAL BLOCK 1	(R PHASE)	R/L1			
	FROM TERMINAL BLOCK 2	(Y PHASE)	S/L2			
	FROM TERMINAL BLOCK 2	(B PHASE)	T/L3			
DRIVE OUTPUT	MAIN CONTACTOR-L1		U/T1			
	MAIN CONTACTOR-L2		V/T2			
	MAIN CONTACTOR-L3		W/T3			
			B1	Connect to DBR One End		
			B2	Connect to DBR Other End		
	WIRE FERRULES NAME					
	UP	(FORWARD)	S1			
	DN(DOWN)	(REVERSE)	S2			
	S4	(SPEED ARD)	S3			
	X5	(DRIVE RESET)	S4			
	S3	(HIGH SPEED)	S5			
	S1	(SLOW SPEED)	S6			
	S2	(MEDIUM SPE)	S7			
	VCOM/ARD CM	(COMMON)	SC			
	M	TRIP RLY NO	MB			
	M	TRIP RLY COM	MC			

